





BEFORE MOUNTING, PLEASE READ THE USER MANUAL FOR CABLING AND CONNECTION DETAILS.


Mounting Guide

DOT XL-6

DOT XL-9



Mounting the Dot XL



Mounting the LED Engine and Pixel Distributor

LED Engine mounts on top of the Pixel Distributor (LED Engine is ordered separately)

Mount Pixel Distributor with connectors facing down

